



## INSTRUCTION MANUAL


### 取扱説明書

矢印一覧  
Arrow List

取付けます。  
Attachable

取り外します。  
Removable

可動します。  
Movable



AGES  
15&UP



**WARNING:**  
CHOKING HAZARD - Small parts. Not for children under 3 years.



**CAUTION** for ages 15 and up.

- Please handle with care and store out of the reach of children younger than 15 years old.
- This product may contain small parts. May be harmful if swallowed.
- This product may contain parts that have sharp points and edges. Please handle it carefully to avoid getting injured.
- Do not place this product on top of plastic furniture, sofa, sheet, tile or anything made of resin. It may cause color migration.
- Color, style and decoration may vary.



**注意** お買い上げのお客様へ 必ずお読みください。

- 本商品の対象年齢は15才以上です。対象年齢未満のお子様には絶対に与えないでください。
- 小さな部品がありますので、小さなお子様が悪く誤って飲み込まないように注意してください。窒息などの危険があります。
- 尖った部分や鋭い部分がありますので、取扱や保管場所に注意してください。思わぬケガをするおそれがあります。

#### < DIRECTIONS >

- Please do not use excessive force when bending, pulling or attaching movable parts.

#### < 使用上の注意 >

- 本商品は精密に作られています。無理な力を加えたり、落としたりすると破損するおそれがあります。
- 可動部分・取付部分を無理な方向に強く引っ張ったり、曲げたりしないでください。
- 本商品を樹脂製のソファやシート、タイルなどの上に置かないでください。長時間接触していると色がる場合があります。